

### MOUNTING LOCATION:

Left side of climate control

### TOOLS REQUIRED:

Phillips screwdriver

### HARDWARE INCLUDED:

None

### CELL PHONE & MEDIA MOUNT

### INSTALLATION INSTRUCTIONS

PART#: **75141-401**  
MFG: **FREIGHTLINER**  
MODELS & YEARS:  
**Business Class FL (ALL), 1994-2003**

### \*\* ADVISEMENT \*\*

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: Carefully release the small bezel that surrounds the climate control. Start by pushing down the sides at the top of the bezel, and pull out to release the clips. Continue working your way to the center of the bezel, releasing (4) total clips. Push bezel up from the bottom to release (3) more clips. Set bezel aside.

STEP #2: With Phillips screwdriver, remove (2) screws on the left side of the climate control. Place the InDash by PanaVise over the screw holes and reinstall the (2) screws.

STEP #3: Reinstall the bezel carefully as to not break any of the (7) clips.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT



Prototype installed showing location



05-06-02